



Couples Toys

ENGLISH

User manual

To enhance the fun with this product and to ensure proper and safe use, please read the following instructions carefully before use.

Safety instructions

- Always check your product carefully before use. Do not use the product if it has any defects like broken, sharp or scratched material.
- Do not use this product if you are allergic to any of the used materials, which you can find on the packaging.
- Do not use this product on irritated skin or recently injured areas.
- For extra comfort use a water-based lubricant. Oil- and silicon-based lubricants may damage the materials.
- If you are experiencing any discomfort or pain, stop using this product immediately.
- These products are designed to prevent it from being inserted too deeply. Always make sure a part of the product is always outside your body, as this allows you to remove the product.

Cleaning instructions

- Clean your product before and after use.
- Use warm water and mild soap or a toy cleaner to clean this product.
- Make sure the product is 100% dry before storing.

Storage instructions

- Store this product in a dry, dust-free place at room temperature.
- Do not expose to direct sunlight.
- Keep your products separate from each other to avoid chemical reactions. For example, you could use a small box or a satin pouch.

Instructions for rechargeable products

- Do not charge your product in or around water.
- Only use the provided USB charger cable, using a different cable might damage the product.
- Do not force the charging cable, or you might damage the connectors. Make sure the plug aligns with the port, then connect it.
- Plug your charging cable into a USB port.

Environmental protection

- Please recycle your packaging materials in accordance of your local recycling guidelines.
- The “crossed-out bin” symbol indicates that this product, and the batteries it contains, cannot be disposed with household waste. The symbol indicates separate collection for electrical and electronic equipment.

Warnings

- Keep this product and packaging out of the reach and sight of children.
- Sold as an adult novelty, not for medical use.
- Do not share this product with others.
- Do not heat or cool the product, unless recommended to do so.
- Do not excessively or forcefully bend, stretch, or obstruct the mechanical movement of the product to avoid malfunction of the inside mechanics or external damages.
- If the product is not water- or splash proof, do not use it in or near water.
- For waterproof products, make sure the battery compartments are closed before using it in water.
- Splash proof products cannot be used in water but can be cleaned with water.
- Keep the product and batteries away from fire.
- The supplier cannot be held liable in any way for defect or damage caused by incorrect use.

Warranty

The legal warranty applies to this product and guarantees within the warranty period and under normal use that the product is free from material and manufacturing defects. Normal wear and tear is excluded from this warranty. The starting date for warranty coverage is the date you purchase the product. Your sales receipt with the receipt number, product description, original date of purchase, price, and reseller details constitutes a valid proof of purchase.